

Work Practices NOT TO DO

Clean-up your work area by hosing materials into a storm inlet!

Track sediment or other debris across sidewalks or streets!

Wash off any tools or equipment into a storm inlet!

Leave bare soil areas unprotected for more than 15 days!

Forget to inform your employees of good storm water practices!



MORE INFORMATION

IDEM Manual for Storm Water:
<http://www.in.gov/idem/4899.htm>

This guidance brochure is for basic storm water requirements. For a complete list of storm water regulations for construction sites go to Rule 5 of the Indiana Administrative Code:
[www.in.gov/legislative/iac/T03270/
A00150.PDF](http://www.in.gov/legislative/iac/T03270/A00150.PDF)

Contact Hancock County MS4s and Partners for more information or questions.

Town of McCordsville
#317-335-3151

Hancock County
#317-477-1150

Town of New Palestine
#317-861-4727

Town of Cumberland
#317-894-6203

Town of Fortville
#317-485-4044 Ext 103

City of Greenfield
#317-325-1327

Solid Waste Management District
#317-462-7605

Soil and Water Conservation District
#317-462-2283 Ext 3

Hancock County MS4 Partnership

Storm Water Protection



Guidance for Contractors

Keep our Water CLEAN

What is storm water pollution?

Storm water pollution is anything other than **rain or snowmelt**

that enters a storm drain.

Storm drains in our County lead directly to a stream and do not get treated in any way.

What is Hancock County MS4s Partnership doing to reduce storm water pollution?

Our MS4s have implemented a Storm Water Quality Management Plan in accordance with the Environmental Protection Agency and the Indiana Department of Environmental Management. This plan includes six minimum control measures that help minimize the pollution in storm water runoff:

Public Education and Outreach

Public Participation and Involvement

Illicit Discharge Identification and Elimination

Construction Site Storm Water Runoff Control

Post-Construction Storm Water Runoff Control

Pollution Prevention and Good Housekeeping

The components of the Construction Site Storm Water Runoff Control minimum control measure in our MS4s Plans can be found in Rule 5 of the Indiana Administrative Code.

Work Practices

MUST DO's

Sweep pavement of any sediment, concrete cutting dust, trash, vegetation, etc and dispose of properly away from storm inlets!

Seed/mulch or install an erosion control blanket on disturbed soil that will not be worked for 15 days or more!

Protect all storm inlets in the work area prior to starting work!

Store all fuels and hazardous materials with secondary containment out of the weather!

Wash paint brushes, drywall tools, concrete tools, equipment, etc well away from storm inlets!

Provide a containment for concrete trucks to wash-out their equipment!

Inspect and repair all storm water practices weekly and prior to and following a rain event!

Obtain storm water training for employees!

Contractors what is your responsibility?

Your contract requires that you prevent the pollution of our storm water systems.

Know the requirements of your Storm Water Pollution Prevention Plan or a general storm water BMP's (Best Management Practices) guide.

